




EcoFlow Blade Battery Quick Start Guide



For more details, please scan the QR code or visit:
<https://www.ecoflow.com/support/download/blade-battery>

Product Overview


Produktdetails/Détails du produit/Dettagli sul prodotto/Datos del producto/
Productgegevens/Описание устройства



Check the state of charge

Überprüfen des Ladestatus/Vérifiez l'état de la charge/Controllare lo stato di ricarica/
Controleer het accuniveau/Проверьте состояние заряда

Press & hold ⑥/Drücken und halten Sie ⑥/Appuyez et maintenez ⑥/
Tenere premuto ⑥/Houd ⑥ ingedrukt/Нажмите и удерживайте ⑥




01


Remove the old battery

Entfernen des alten Akkus/Retirez l'ancienne batterie/Rimuovere la vecchia batteria/Verwijder de oude accu/Извлечение батареи

1. Remove ①/Entfernen ①/Retirez ①/Rimuovere ①/Verwijder ①/Удалить ①



2. Press & hold ③/Drücken und halten Sie ③/Appuyez et maintenez ③/
Tenere premuto ③/Houd ③ ingedrukt/Нажмите и удерживайте ③



ECOFLW




02


Install the new battery

Einsetzen des neuen Akkus./Installez la nouvelle batterie./Installare la nuova batteria./Instale la nueva batería./Plaats de nieuwe accu
Установите новую батарею



1. Set up the battery. /Einsetzen des Akkus. /Installez la batterie. /
Installare la batteria. /Instale la batería. /Plaats de accu /Установите батарею



2. Mount back ❶/❶ wieder anbringen/Réinstallez ❶/Installare nuovamente ❶/
Instalar de nuevo ❶/Plaats ❶ terug/Установите обратно ❶



3. Lightly tap ❶/❶ leicht klopfen/Tapotez légèrement ❶/
Picchiettare leggermente ❶/Golpea ligeramente ❶/Tik lichtjes op ❶/
Слегка постучите по ❶



Keep the battery inside for charging

Belassen Sie den Akku zum Laden im Mäher./Gardez la batterie à l'intérieur de la tondeuse pour la charger./Per la ricarica, mantenere la batteria all'interno del tagliaerba./Mantenga a batería en el cortacésped para cargarla./Houd de accu voor het opladen in de grasmaaier./Оставьте батарею внутри косилки для ее зарядки.